



## INSTALLATION INSTRUCTIONS:

- Ensure main supply is switched off.
- Insert masonry plugs (A) into mounting surface.
- Fit mounting board onto outlet box with screws (B).
- Connect wires (C) according to color (White to White, Black to Black). Connect all earth plug together onto the mounting board with green screw to tight.
- Fit the body (D) onto mounting board with screws (E).
- Reconnect power.

## WARNING:

- This fitting must be earthed.
- Disconnect power and allow fitting to cool down before cleaning or changing the lamp.